


ED 16

2002-Present



O.E. Inner Spacer (2)Washers (2)Bearings

Extra Duty - 16 times stronger than O.E. bearings.

Instructions

Remove stock spherical bearing from O.E. inner spacer.

Install ED 16 bearings with two washers on each side -
per illustration above.

Install ED 16 bearing with spacer into swing-arm per H-D service manual.

INNOVATIONS / STA-BO, LLC

Murfreesboro, TN 37130

615-895-8993

www.sta-bo.com